

STEPS FOR ELAN'S U132/U111

This document is intended only as a supplement to Elan's documentation that comes on the CD-ROM supplied with their products, and their website. Please follow those instruction carefully.

1

Install the drivers for your 3G Wireless card first! These come with your Wireless card. Questions regarding that installation must go to the card manufacturer or your wireless carrier.

2

Place the Elan CD-ROM into your drive before plugging anything in.

3

Do not place the Wireless PC Card into the U132 or U111 at this time. Plug the U132 or U111 into an available USB port on the host system (computer).

4

Follow the instructions in Elan's installation guide to install the correct drivers for the U132 or U111. If installed correctly, the MS Windows "device manager" will show a USB PC-Card Readers entry like that on the right hand side of this document.

5

Insert the 3G Wireless PC Card into the U132 or U111, follow Elan's instructions for this stage, and double check the "device manager" for modem entry with your wireless card's name.

6

If you have a card that requires a manual connection setup, follow Elan's instructions for those steps. Use the phone number, username, and password provided by your wireless carrier. Most cards do not require the "Advanced" settings mentioned in Elan's documentation.

